


REPLACEMENT PARTS LIST

Save for future reference

Floor Machines

Models GB17F, GB20F


HANDLE ASSEMBLY



Ref.	Part No.	Description	Qty
1	B001305	Switch Box Decal	1
2	B001306	Cover Switch Box	1
3	B001307	Instructional Decal	1
4	B001308	Pin	1
5	B001309	Spring	1
6	B001310	Safety Latch	1
7	B001311	Safety Latch Support	1
8	B001312	Screw	1
9			1
10	B001314	Handle Tube	1
11	B001315	Handle Grip	2
12	B001316	Trigger	1
13	B001317	Insulator	1
14	B001318	Screw	2
15	B001319	Micro Switch	1
16	B001320	Insulator	1
17	B001321	Washer	1
18	B001322	Hex Nut	1
19	B001323	Round Screw	2
20	B001324	Washer	1
21	B001325	Round Screw	1
22	B001326	Spring	1
23	B001327	Wire	1
24	B001328	Socket Cover	1
25	B001329	Socket	1
26	B001330	Insulator	1
27	B001331	Screw	1
28	B001332	Gasket	1
29	B001333	Caution Decal	1
30	B001334	Cord Grommet	1
31	B001335	Pigtail	1
32	B001336	Cord Set 50'	1
33	B001337	Hex Cap Screws	1
35	B001339	Cord Hook Brace	1
36	B001340	Cord Hook	1
37	B001341	Pipe handle	1
38	B001342	Cord Set Short	1
39	B001343	Cord Connector	1
40	B001344	Cord Support	1
41	B001345	Handle Boot	1

CHASSIS ASSEMBLY

Ref.	Part No.	Description	Qty
1	B001346	Screw	1
2	B001347	Canopy Spacer	1
3	B001348	Motor	1
4	B001349	Locking Cam Grip	1
5	B001350	Locking Cam	1
6	B001351	Washer	9
7	B001352	Handle Clamp	1
8	B001353	Nut	1
9	B001354	Handle Support (left)	1
10	B001355	Handle Support (right)	1
11	B001356	Washer	2
12	B001357	Axle Nut	2
13	B001358	Wheel	2
14	B001359	Wheel Axle	1
15	B001360	Bolt	1
16a	B001361	17" Frame	1
16b	B001362	20" Frame	1
17	B001363	Frame Interlock	1
18	B001364	Spring Gasket	1
19	B001365	Socket head Screws	1
20	B001366	Bolt	1
21	B001367	Hose Connector	1
22	B001368	Hose	1
23a	B001369	17" Chassis	1
23b	B001370	20" Chassis	1
24a	B001371	17" Bumper	1
24b	B001372	20" Bumper	1
25	B700016	Clutch Plate	1



BOSS
CLEANING EQUIPMENT

www.BossCleaningEquipment.com