


FREEFLEX PARTS



No.	Product Name	Qty	List Price
1	107502 Four-Layer Synthetic Filter, Fits FreeFlex	10/pk	\$ 35.51
2	510657 Upper Service Assembly (includes: 3-18)	1 set	312.76
3	841322 Handle Assembly	1 ea.	46.80
4	840495 On-Off-On Switch	1 ea.	3.43
5	835348 Screw, Machine M5	1 set	3.95
6	510425 Aluminum Tube Handle	1 ea.	11.86
7	510427 Carry Handle Assembly (includes: 8)	1 set	12.63
8	835345-1 Screw M4 Pan HD	1 set	3.72
9	840386 Foam Filter Bag Housing	1 ea.	128.43
10	840414 Aluminum Handle Mount Bracket	1 ea.	8.67
11	510433 Filter Mount Brackets Assembly (includes: 12)	1 set	16.46
12	840509 Filter Mount Pivot Bracket	1 set	7.60
13	510434 Bottom Filter Plate Assembly	1 set	11.39
14	510654 Bag Switch Detect	1 ea.	8.76
15	840499 Debris Tube	1 ea.	23.75
16	840506 Screw M3 CS Pan HD	1 set	7.92
17	510430 IEC Connector Plug Assembly (includes: 16)	1 set	15.17
18	510429 Battery Mount Plates Assembly (includes: 16, 17)	1 set	35.78
19	840377 Power Cord	1 ea.	34.95
20	107500 FreeFlex Cordless Upright Replacement Battery	1 ea.	1,076.25
21	510428 Debris Tube Brackets Assembly	1 set	11.02
22	510431 Debris Tube Clamp Assembly	1 set	15.20
23	510655 Debris Tube Brackets (includes: 21, 22)	1 set	22.26
24	510437 Base Cover Assembly	1 ea.	38.89
25	510661 Motor Cover	1 ea.	37.93
26	510420 Motor Cover Assembly (includes: 25)	1 set	10.90
27	510664 Blower Motor (includes: 28-31)	1 set	132.20
28	510435 Blower Housing Assembly	1 set	21.77
29	510416 Blower Wheel Assembly	1 set	12.92
30	835345-1 Screw M4 Pan HD	1 set	3.72
31	510415 Motor Assembly	1 set	96.62
32	510658 Inlet Nozzle	1 set	18.69
33	510656 Pivot Bracket (includes: 34, 35)	1 set	36.75
34	510418 Right Pivot Bracket Assembly	1 set	19.16
35	510417 Left Pivot Bracket Assembly	1 set	18.94
36	510421 Pivot Bracket Clamp Assembly	1 set	5.45
37	840490 Main Control Board	1 ea.	111.74
38	840070 Side Base Upright Bumper	1 ea.	10.59
39	510662 Base with Rear Wheels (includes: 40-42)	1 set	63.75
40	510414 Rear Wheel Shaft Assembly	1 set	3.76
41	841324 Rear Wheel Assembly	1 set	8.37
42	840369 Power Nozzle Base	1 ea.	45.10
43	834363 Wheel/Axle Replacement Kit	1 set	10.41
44	510659 Foot Pedal Assembly (includes: 45, 46)	1 set	11.65
45	840475 Foot Pedal	1 ea.	9.44
46	510422 Foot Pedal Shaft Assembly	1 set	8.22
47	843009 Control Board Hall Effect Sensor	1 ea.	26.15
48	835937 Screw M3 Pan HD	1 ea.	3.33
49	510424 Brush Release Button Assembly	1 set	5.64
50	841325 Brush Removal Cover Assembly	1 ea.	10.78
51	840167 Brush Roller Assembly	1 ea.	21.13
52	841814 Clutch Assembly	1 ea.	20.26
53	841744 Belt 168XL037	1 ea.	12.35
54	510663 Drive Brush (includes: 49-53)	1 set	61.22
55	510423 Rear Base Plate Assembly (includes: 56)	1 set	6.56
56	840194 Base Wire Brace	1 set	5.65
57	840191 Squeegee Blade	1 ea.	3.23
58	841323 Front Plate Assembly	1 set	14.74
59	510660 Front Rear Plates (includes: 55-58)	1 set	25.31
60	840069 Front Base Upright Bumper	1 ea.	15.21
61	107501 FreeFlex Cordless Upright Replacement Charger	1 ea.	394.58
62	834678 Charger Cord	1 ea.	37.44
63	843108 Clog Removal Tool	1 ea.	13.67
510432	Screw/Washer Assortment (22 piece set)	1 set	10.77
510436	Gasket Assortment (5 piece set)	1 set	6.81