

Spare parts list



GS Ecobot
50



CLICK TO ORDER PARTS



Table of contents

TASKI GS Ecobot 50P V3.7	3
--------------------------	---

TASKI GS Ecobot 50P V3.7

Article no.	Description	Quantity	Unit
4135287	Hem strips-magnetic suction	1	PC
4135288	Brush plate front strip	1	PC
4135289	Suction stripping front rubber	1	PC
4135290	Absorb water scrape back rubber	1	PC
4135291	Clean water/sewage filter	1	PC
4135292	Filter B component	2	PC
4135293	Suction tuyere	1	PC
4135294	Wheel 1.6 inch	1	PC
4135374	Pull cord	1	PC
4135375	Pipe	1	PC
4135376	Plug	1	PC
4135377	Charger 25A	1	PC
4135380	LiFePo battery 60AH	1	PC
4135387	ES5129 IPC-I5 4200H	1	PC
4135353	Lidar	1	PC
4135389	LiVox LiDar	1	PC
4135390	Dabai camera module	1	PC
4135391	Motor controller	1	PC
4135392	Servo Drive	1	PC
4135393	Brushless drive	1	PC
4135394	Vacuum motor	1	PC
4135395	Short shaft motor	1	PC
4135396	Linear actuator	1	PC
4135397	Linear actuator-roller brush	1	PC
4135399	Brush disc motor	1	PC
4135400	Brushless motor	1	PC
4135401	Solenoid valve	1	PC
4135402	Two-way electrical ball valve	1	PC
4135403	Three-way electrical ball valve	1	PC
4135404	4G Network AP (EC25-E)	1	PC
4135405	Android all-in-one PC	1	PC
4135406	Ultrasonic probe	1	PC
4135407	LoRa wireless node module	1	PC
4135408	TTL to RS485 Module(with isol)	1	PC

TASKI GS Ecobot 50P V3.7

Article no.	Description	Quantity	Unit
4135409	Pro800 Lower Computer-Injection	1	PC
4135475	Sewage funnel	1	PC
4135559	Key	1	PC
4135605	Bellows-L230	1	PC
4135739	Docking connection set	1	PC
4135903	Air pressure strike plate front assembly	1	PC
4135906	Bellows-L200	1	PC