

93222 EB 30/1 Electric Broom




CLICK TO ORDER PARTS

TABLE OF CONTENTS

Main Assembly	3
Accessories and Consumables	6

Main Assembly



Rendered by LeadVenture, Inc.

Main Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	K40810020	Complete Bottom Part		1
2	K43240240	Pushbutton w/Spring		1
3	K52501470	Right Bearing		1
4	K44540003	Complete Transmission and Right Bearing		1
5	K46540290	Li-Ion Battery	Battery and Wall Charger Li-Ion Battery and Wall Plug Charger part number K46540310.	1
	K46540310	Li-Ion Battery and Wall Plug Charger		1
6	K73031290	Screw M4 x 16		11
7	K63484270	Belt		1
8	K40705980	Complete Tube		1
9	K40706060	Hand Grip		1
10	K46237500	Motor		1
11	K66458390	Wall Plug Charger for Li-Ion Battery Eb 30/1	Battery and Wall Plug Charger Li-Ion Battery and Wall Plug Charger part number K46540310.	1
12	K47624000	Black Roller Brush		1
12	K47624010	Red Roller Brush		1
13	K48800580	Front Wheel and Axle (Set of 2)		1
14	K40705880	Complete Sweep Tank		1
15	K46820920	Complete Electronics		1
16	K48224340	Electrical Plug		1
17	K66304130	Switch		1
18	K66541970	Quick Charger		1
19	K55152760	Wheel		2
20	K63431870	Lock Washer		2

Ref Number	Part Number	Part Description	Context Notes	Quantity
21	K50087750	Left Bearing Plate		1
22	K46721810	Locking Part		1
23	K56053140	Joint		1
24	K41100130	Thrust Piece		1

Accessories and Consumables

1



2



3



Rendered by LeadVenture, Inc.

Accessories and Consumables

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	K46540290	Li-Ion Battery		
2	K47624000	Black Roller Brush		
3	K47624010	Red Roller Brush		