

98780 (Deluxe Model)




CLICK TO ORDER PARTS

TABLE OF CONTENTS

Main Assembly	3
---------------------	---

Main Assembly



Main Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	04-0286-0000	Cable Clamp		1
2	PD3B	Tall Dryer Foot		4
3	PX73	Screw #8-32 x 1"		2
4	X1022	Circuit Breaker 9A		1
5	X8235	Washer		5
7	X8256	Keps Nut		4
8	X8261	Screw #6 x 1/2" (Black)		4
9	X8278	Screw #8-32 x 1/2"		2
10	X8459	Serial Number Label		1
11	X8871	Discharge Grill		1
12	X8874	Dryer Kickstand		1
13	X8897	Switch		1
14	X8903	Screw M4 x 6		2
15	X8928	Right Foot		1
16	X8929	Left Foot		1
17	X8946	Rivet		2
18	X8976	Warning Label		1
19	X9674-115.2-AL	Motor 115 VAC w/14uf Capacitor		1
Not Shown	X9674C	Capacitor 14uF		1
20	X1023	Fan Blade		1
21	X9676	Screw #8-18 x 3/4"		13
22	X9700	Bottom Housing		1
23	X9701	Top Housing		1
24	X9702	Bolt 1/4-20 x 2-3/4"		5
25	X9704	Screw #8-18 x 3/1/2"		2
26	X9705	Rubber Grommet		1

Ref Number	Part Number	Part Description	Context Notes	Quantity
27	X1002	Power Cord 14/3 x 20' SJTW		1
28	X9757	Power Outlet Assembly		1
29	X9726-TOR	Front Label		1
30	X9727	Warning Label		1
31	X9728-TOR	Switch Label		1
32	X9731	Cap		4
33	X9831	Knob		1